

INSTALLATION INFO for DNA filter P-H6S07-0R

For: Honda CBR 600 RR 2007'

The DNA High Performance filter P-H6S07-0R is designed to replace the CBR 600 RR 2007 stock replacement filter,
To install or later remove your DNA filter for cleaning it, please follow the detailed info listed below:
(we recommend that the installation should be carried out by a trained mechanic)

1. Unbolt the top of the airbox to access the 2 screws that secure the stock filter in place.

Unscrew carefully and remove the stock filter.

Pay attention NOT to drop the 2 screws in the airbox!

Clean the airbox carefully, removing all the debris.

2. The DNA filter uses a high quality EVA foam gasket to seal the filter against the airbox. In order to achieve a perfect sealing and help the filter slide easily in place apply a small amount of DNA air filter sealing grease (included) on the EVA foam gasket.



3. Install the DNA filter in the airbox carefully.

Check that all 3 tabs are located properly in place.



Push down the filter and screw carefully the 2 screws (provided with the DNA filter) using a Philips screwdriver.

Attention Do not Over tighten the filter!

Carefully close the airbox and the installation is completed.

Follow the Service Kit Instructions to service.
Re-install following the installation procedure again.

www.dnafilts.com

Made in EU / Greece

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.