



**INSTALLATION INFO for
DNA stage 2 air box cover :**
TC-KT6SM09-S2 KTM 690 SMC/ENDURO/R 08'-09'

DNA STAGE 2 TC-KT6SM09-S2 KTM 690 SMC/ENDURO/R Air box cover is designed to replace the stock air box COVER and in cooperation with the DNA High Performance Filter R-KT6SM09-0R (not included) to increase the airflow, Power, Torque and Throttle response.

The following procedure is necessary if you use the DNA air box COVER.

1. Open the air box by removing the stock cover intake.
2. Remove the std. paper filter.
3. Install the DNA filter **R-KT6SM09-0R** (must be purchased separately) **in the air box** and the stage 2 air box COVER **TC-KT6SM09-S2** (see photo below) and secure using the 2 stock bolts.

Do not over tighten!



4. **Attention!** When washing the bike the air box intake must be covered, to stop the water entering the air box. If by mistake the air box is flooded, it must be cleaned and dried BEFORE starting the bike, or else damage to the engine can occur.

5. WARNING..!

Fuel injection **recalibration** is absolutely necessary! Please use a Dynojet Powercommander or similar product to correct your fueling or else the bike will run lean and possible damage will occur.

Note: Although the Stage 2 cover will work with the stock filter, for maximum air flow it is recommended to use the stage 2 DNA COVER in cooperation with a DNA standard filter designed to replace the stock filter.

For race or closed circuit use only, not legal for road use.

The manufacturer and seller make no warranties express or implied which extend beyond the description of the goods contained herein. Any description of this product is for the purpose of identifying it and shall not be deemed to create an express warranty.