


SHAD

BMW S1000 XR '15 KIT TOP W0SX15ST



1 261914 x1 →
261915 x1 ←



2 303017 x4
Ø6



3 303018 x2
Ø8



4 260213 x2
Ø16 x Ø9 x 12



5 260538 x4
Ø16 x Ø9 x 8



6 304079 x4
M6 x 30
Din 7380



7 304029 x2
M6 x 35
Din 7991



8 303045 x2
Ø8



9 304058 x2
M6 x 30
Din 965



10 200713/2
x2

! WARNING!

(GB)

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

(E)

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

(D)

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

(I)

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

(F)

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

